

Square Tanks BOM	
Part	Qty
Center Tube (18" or 28")	1
End Cap; Left	1
End Cap; Right	1
End Cap O-Ring	2
Connecting Rod (18" or 28")	4
5/16-18 x 1.5" Connecting Rod Hardware (Black or Clear Zinc)	8
3/8-16 x .75" Grade 8 Yellow Zinc Tank Mounting Hadware	4
3/8" Split Lock Washer Yellow Zinc	4
3/8" Flat Washer Yellow Zinc	4
1/8" NPT Pipe Plug Nickle Plated Brass	4
3/8" NPT Pipe Plug Nickle Plated Brass	6
7g Pouch Loctite Anti-Seize	1
1cc Pouch Super Lube Synthetic O-Ring Lube	1

## **Assembly Procedure**

Install o-rings in end cap o-ring grooves using o-ring lubricant. O-rings should fit snug and evenly around the end cap.

Loosely assemble end caps & connecting rods on the tube. Confirm end caps are aligned with each other.

Install connecting rod hardware using anti-seaze lubricant on the threads and torque to 18ft lbs.

www.squaretank.com I 800-928-1984 I info@squaretank.com

200psi max pressure. This product is for show/off road use only

Raw tubes are not UV protected. Raw tubes must be wrapped or painted before use

Tanks with Raw tubes are shipped loosely assembled

Tanks with Cerakote tubes are factory sealed & assembled